

# M87 mac

Backlit Mechanical Keyboard

Screen Brightness Multimedia Controls  
 Function Keys Caps Lock Indicator  
**USER GUIDE**


## 01

### KEYBOARD SPECIFICATIONS

- Product: Velocifire mechanical keyboard for Mac
- Model: M87
- Connector type: USB2.0 (150cm)
- Cable length: 59 inches/150cm
- Product weight: 1.42 pounds/646g
- Switch: Brown Switch
- Color: Space Gray
- Backlighting color: LED White
- Keycaps: ABS Painting and Laser
- Key number: 87 keys
- Service life: >50 million key strokes
- OS support: macOS
- System requirements: iMac, MacBook, Mac mini, Mac Pro (Available: USB port)
- Anti-Ghosting

## 02

### DEVICE LAYOUT



**A Screen Brightness**

**C Multimedia Controls**

**B Function Keys**

**D Caps Lock Indicator**

COMBINATION/HOTKEYS

F1-F12 function

- F1 – Decrease Screen Brightness
- F2 – Increase Screen Brightness
- F3 – Explore
- F4 – Dashboard
- F7 – Previous track
- F8 – Start/Pause
- F9 – Next track
- F10 – Mute
- F11 – Volume down
- F12 – Volume up

FN+

- ↑: Increase brightness up to 5 levels
- ↓: Decrease brightness down to 5 levels (backlit can be adjusted to off)
- ↔: Decrease backlit breathing frequency
- ↔: Increase backlit breathing frequency

FN+(Game mode)

- 1: FPS
- 2: CF
- 3: COD
- 4: RTS
- 5: LOL full style
- 6: Car race
- 7: NBA
- 8: LOL simple style
- 9: Self design
- 0: Self design

FN+

1. Ins: Enter the normal light mode

Press again to game lighting mode (when you select any game mode);  
 Press again to breathing light mode;  
 The backlight keeps on. When a keypad is pressed, the backlight LED of the corresponding keypad will be off. When the keypad is released, the backlight of the keypad will fade away.

2. Home: Enter the Point Color mode

The whole backlight is off. Each time a keypad is pressed, two light waves are scattered to the surrounding from the center.

Press again to enter the Imminent mode

The whole backlight is off. Each time a keypad is pressed, lightening up the row that the pressed keypad belongs.

Press again to enter the Key Ripple mode

The whole backlight is off. When a keypad is pressed, the backlight LED of the corresponding keypad will be lit. When the keypad is released, the backlight of the keypad will fade away.

3. Page up: Enter the Flowers and Riches mode

The scrolling backlit starts from the the top left to reach the center "O" key, and then enlarges to the whole keyboard.

Press again to enter the Racing Lights mode

The backlight, starting from the ESC key row, moves from left to right to-and fro.

Macro-recording function (self design)

1. Press FN+9/0 turns on self-design, then press FN+END;
2. Press any keys, and the keys backlight is normally lit;
3. Press FN+END to close this set of macro definitions.

\* Fn+Esc: press up to 1 time, the keyboard backlit flickers 1 time, the keyboard restores manufacturer default setting.

4. Delete: Enter the Drift1 mode

The backlight moves from left to right in an orderly manner, as if it were a shimmering water.

Press again to enter the Drift2 mode

The brightness of the backlight varies from left to right in an orderly manner, as if the waves are constantly surging.

5. Page down: Enter the Stars, Dot. mode

The backlight is like the stars in the night sky. Scintillation speed and quantity can be adjusted according to user's preference.

Press again enter the Flow mode

The backlight runs back and forth in opposite directions.

Press again to enter the Diagonal mode

The backlight runs from top left to bottom right, and from top right to bottom left.

Press again to enter the Sine Wave mode

The backlight is off, a light waving in the form of sinusoidal up and down.

\*Any mode can Decrease/Increase Backlit Breathing Frequency.

GLOBAL WARRANTY POLICY

Warranty periods of Velocifire mechanical keyboard for Mac
Model: M87
Warranty: 1 Year
This warranty gives you specific legal rights. You may also have other rights granted under local law. These rights may vary.

WARRANTY AGREEMENT

If the product has defects in material or manufacture, Velocifire will provide product repair and replacement service within the warranty period.
Our warranty service is based on the date. We will apply the original shipping date of the product as the beginning date of the warranty period. The shipping date will be identified by order website and number.

CONDITIONS WHERE FREE MAINTENANCE IS NOT PROVIDED

- Any fault or damage caused by natural disaster (including storm, fire, flood, thunder, earthquake, etc.).
Any fault or damage caused by accident factors and man-made reasons (including hit, scrape, crash, moving, compression, stain, corrosion, use of incurred on unsuitable voltage, computer virus, riot, misuse, malicious damage, etc.).
Use in an improper operating environment (including high temperature, high humidity, water inflow, etc.).
Inability to provide the product the warranty card or order details to prove the product is still within the warranty period and the order details of the product is out of warranty.
The warranty card or product serial number has been altered or its number is hard to identify.
The warranty period has expired.
Any fault or damage caused by non-compliance with regulations stated in the user manual or improper, rough and careless treatment.
Any fault or damage caused by the use of parts not certified by Velocifire original manufacturer.
The problem is caused by improper repair or adjustment by the buyer or any manufacturer without authorization from Velocifire.
The product is not acquired from an authorized of the company or is acquired from illicit sources.
Paper carton, instruction, and other accessories are not warranted.



GLOBAL DISCLAIMERS POLICY

- Velocifire product is not authorized for use as critical components in lift support device or for incorrect application software or malfunction of the product.
Velocifire is not liable for the death or damage of person or loss of property when the product is using as, including but not limited to, medical equipment, military equipment, traffic equipment and disaster prevention system.
Velocifire's warranty liability is limited to repair, replacement.
Velocifire is not liable for any damages, expenses, lost data, lost revenues, lost savings, lost profits, or any incidental or consequential damages due to using defect product of Velocifire.
If you have any question about the warranty, please feel free to contact us.
Customer support: service@velocifiretech.com

TRADEMARK STATEMENT

- Any word, slogan, symbol or design (brand name, logo) that distinguishes the products or services offered by Velocifire have been trademark protected. Relevant trademark registration information is accessible through public official trademark database by country.
Any unauthorized use of the above-stated trademark may infringe the trademark right of Velocifire, for any potentially infringing activity, Velocifire reserves all rights to take any legal action and pursue any right or remedy available under applicable law.

IN THE BOX

87 keys mechanical keyboard
key puller
User Manual

CONTACT

Service email: service@velocifiretech.com
f @Velocifire
More information you will find at www.velocifiretech.com
All right reserved

