

Calc / Pen Set 7737

A. FEATURES:

1. Calendar/Timer
Calendar Clock displaying calendar, year, month, date, hour, minute and second.
2. Daily Alarm Clock
To set one alarm in specific time of day.
3. World Time
16 cities world time display
4. Calculator/Currency Converter
8-digits calculator consists function +, -, ×, ÷, M+, M-, MRC
5. Selectable key Tone Function
6. Built-in Counter down timer.

B. CALENDAR/TIME SETTING

After setting of any mode. Press **(TIME)** to return to normal time display.

1. Press **(▲)** or **(▼)** key to scroll calendar by month.
2. Press **(▲)** or **(▼)** key for 5 seconds to search calendar quickly.
3. Press **(TIME)** key and the **(SET/RC)** key to enter Calendar/Time Setting Mode.

Display will start flashing from second.

Press **(SET/RC)** to select the setting mode and then press **(▲)** or **(▼)** key to set correct time and date.

*setting mode sequence:
(second)(hour)(minute)(year)(month)(date)

-1-

4. Press **(24)** key to switch between 12-hr and 24-hr time display.

5. TIME SETTING

- a. Press the key correspond to your desired city then the **(SET/RC)** key to set it as HOME TIME.
- b. Press other keys with city names to display time and date in different countries.
(World Time display will last for 8 seconds and then go back to Home Time display.)

C. COUNT DOWN TIMER

Press **(TIMER)** key to enter count down time mode.

1. Press **(SET/RC)** to enter Timer Setting Mode. Display will start flashing from second. Press **(SET/RC)** (**SET**) key to toggle between hour minute and second then use **(▲)** or **(▼)** key to set desired time. Maximum setting is 99 hr 59 min 59 sec. Press **(SET/RC)** key repeatedly until display stops flashing to confirm.
2. Press **(TIMER)** to start/pause the timer. When timer is paused, press **(▲)** or **(▼)** key will reset timer to zero.

D. ALARM TIME SETTING MODE

1. Press **(ALARM)** key to enter ALARM TIME SETTING MODE.

-2-

2. Press **(ALARM)** key to select Alarm ON or Alarm OFF mode.

3. Press **(SET/RC)** key to start hour setting, press **(▲)** or **(▼)** key to set alarm hour.

Press **(SET/RC)** key to jump to minute setting. Then press **(▲)** or **(▼)** to set alarm minute.

Press **(SET/RC)** to finish ALARM TIME SETTING

4. Under ALARM TIME SETTING MODE, press keys **(0)** to **(9)** and "+", "-", "×", "÷", "=", "MRC" to select different sound.

E. CALCULATOR/CURRENCY EXCHANGE MODE

1. Press **(CE)** key to enter CALCULATOR MODE. Calculator operations are +, -, ×, ÷, M+, M-, MRC
2. Press **(CE)** key then **(SET/RC)** key once, input exchange rate (maximum 6 decimal places), press **(SET/RC)** to confirm.
3. Press **(AC)** key, input the amount to be changed, press **(SET/RC)** the rounded result will show.

F. KEYTONE

Under TIME mode, Press **(SET/RC)** to toggle keytone "ON" or "OFF"

G. AUTO RETURN TO CALENDAR/TIME MODE

Under Calculator Mode. Display will automatically return to CALENDAR/TIME (HOME TIME) if no key is pressed for 5 minutes.

H. INSTALLING BATTERY

1. Remove the battery insulator from the battery compartment.
2. Replace the old batteries when the clock display is faint.
3. When take out the isolation or replace the batteries, it is possible that the buttons may malfunction and the display may show irregular graphics. If this happens, simply use a thin stick to push the reset switch from the bottom of the unit.

-4-