

Inflate-a-mals

OWNER'S MANUAL

1. Prepare Toy

A. Rest the Inflate-a-mal™ on a smooth surface. Locate the zipper and unzip the opening.

B. Reach with your hand to the inside. Make sure that all limbs (legs, arms, feet, neck, and head) of the inflatable inner plastic bladder are extended and fit within the outside plush.



2. Connect the Pump

A. Locate and open the air valve (located on the inner PVC bladder inside the zippered area). Insert an electric air pump (sold separately) into the valve and secure the tip tightly.

B. Close the zipper almost all the way (as much as allowed by the valve) while leaving only the valve sticking out.



3. Inflate Toy

A. Turn on the air pump to inflate the Inflate-a-mal™.

B. During the inflation process, adjust and stretch the limbs to fit perfectly, especially in the head, arms, and legs area (if applicable).



4. Close the Valve

A. When the Inflate-a-mal™ feels full and firm to the touch and can sit/stand without assistance, remove the nozzle and close the valve.

B. Push the valve back inside the plastic body making sure the plug is closed tightly.



5. Zipper Closure

A. Ensure that all the interior parts are in place. Grasp both ends of the fabric together and slide the zipper shut.

B. Fold back the flap over the zipper area and enjoy hours of fun.



How to Clean Fabric

Upon fully deflating Inflate-a-mal™, remove the inner plastic liner and set aside. Wash the fabric either by hand or on gentle cycle in a washing machine with mild detergent in cold water. Hang dry - do not place it in dryer. Reinsert inner plastic liner and refer to inflation instructions at beginning of manual.

How to Deflate Toy

Open the air valve. It is recommended to use an electric air pump with a vacuum setting. Insert the air pump into the valve and turn on the pump until the Inflate-a-mal™ is completely deflated. Store the deflated toy for future use.

How to Resolve an Air Leak

We are confident that our products are of excellent quality and meet superior guidelines. As with any item you purchase, there may be a slight chance of malfunction. If your Inflate-a-mal™ has been fully inflated and after 24 hours it seems to gradually deflate, check the bladder valve to ensure it is fully closed and inserted properly. If it is done correctly yet still seems to be deflating, remove the inside bladder and completely re-inflate it. With your hand, in a gentle gliding motion, locate where there may be an opening that's allowing air to escape. Use a standard vinyl repair kit for correction. (Not included.)

Troubleshooting Important Note

If after following all instructions, the Inflate-a-mal™ does not appear as expected, simply remove the deflated inner bladder from the plush cover, and straighten it out on a flat surface. Then, insert it back inside the plush cover from top to bottom (starting with head first, placing all the limbs in its proper place).

Once that is done, proceed with step #2 of the instructions to complete the initial setup, and enjoy your new friend!

CAUTION:

It's important you follow these rules when playing with your Awesome Inflate-A-Mal!

- DO NOT take any keenedged or sharp objects when playing with you Inflate-A-Mal.
- KEEP AWAY sharp object such as, knives, scissors, pencils, pens, nails, push pins.
- Adult Supervision is required to fill your inflate-A-Mal
- DO NOT place near fire, or heater, or ovens
- DO NOT jump on your inflate-A-Mal
- DO NOT use your inflate-A-Mal as a life raft or in the water.
- DO NOT wash your Inflate-A-Mal in a washing machine with the bladder still inside.
- DO NOT try to iron your inflate-A-Mal with or without bladder.