


**Portable Audio Converter
Instructions**




Parts Included:

- A. 1 x Audio Converter
- B. 1 x Remote Control with 1x Lithium Cell CR2025 battery
- C. 1 x Stereo Audio Cable
- D. 1 x RCA Audio Cable
- E. 1 x USB Power Cable



Setup:

1. Power up (A) audio converter with (E) USB power cable to either a USB power adapter (not included) or directly into a computer USB port. The LED light (H) will light up green indicating the device is ON.
2. Insert either a USB drive FAT format (not included) into the USB port (L) or a SD memory card FAT32 format (not included) into the SD memory card slot (M). Note: do not insert both USB drive and SD memory card at the same time. Only use one or the other.
3. Connect the audio source you wish to record from with either the stereo audio cable (C) to line in (J) or RCA audio cable (D) to RCA input (I).
4. Pull the clear tab from the remote control.



Manual Recording Mode:

1. To begin recording manually, press the record button (F) or the red button on the remote control (B). The LED light (H) will blink green. Then play the audio source you wish to record. The audio will be saved as a single mp3 file. Note: you may split the audio files individually during recording by pressing the >>| green button on the remote control (B) at anytime.
2. To end recording press the record button (F) again or the red button on the remote control (B).

Auto Recording Mode:

1. Press and hold the >>| green button on the remote control (B) for 3-5 seconds until the LED light (H) turns blue to set the audio converter (A) to auto recording mode. Repeat the process to change back to manual recording mode.
2. To begin recording automatically, press the record button (F) or the red button on the remote control (B). The LED light (H) will blink blue. Then play the audio source you wish to record. The audio converter (A) will record each song individually.
3. To end recording press the record button (F) again or the red button on the remote control (B).

Locating MP3 Files:

1. Insert your USB drive into your computer's USB port or SD memory card into the SD memory card slot. Find the folder named "Tapemp3" and

click to view your mp3 files. The audio files will be listed as "FV0000.mp3". Note: maximum file capacity range: (FV0001 ~ FV9999).

Optional: Connect the audio converter to external speakers using the line out connection (K).

2. Press the green play button >|| on the remote control (B) to start playing the audio.

Remote Control Functionality:

Red button, Record (●●)

Green buttons:
Play and Pause (▶||)

Rewind (◀◀)

Forward and Skip (▶▶)

Volume down (◀)

Volume up (▶)