


HOW TO CLEAN WATER TANK


Disconnect Power Before Cleaning:

1. Remove Water Tank from top of unit.
2. Remove Humidifier Reservoir cover plate.
3. Wipe Reservoir with soft cloth to remove any film or residue. Gently clean exterior surface with soft damp cloth.
 - 3a. If Humidifier is used daily, the unit should be cleaned weekly.
 - 3b. If unit hasn't been used for a long time, clean before using.
4. Replace Reservoir Cover Plate.
5. Replace Water Tank.
6. Align Slot and two arrows on Water Tank to insure assembly is correct.



FOREVER FRAGRANT® DISCS

Place discs in slots on top of the unit



HOW TO CLEAN THE FILTER

1. Turn unit power off and unplug the adaptor from the wall; then remove the adaptor from the unit.
2. Turn the unit upside down and remove the filter by turning it counter-clockwise until the tabs are aligned with the slots and the filter slides out easily.
3. Gently tap the filter on front & back side to remove large dust and particles or use hairdryer set on low temperature moving back and forth, blow out one side and then the other side for approximately 5 seconds per side.
4. Run the filter under warm running water for 8-10 seconds per side.
5. Allow the filter to dry completely, preferably where it can get air from both sides of the filter. Do not dry in direct sunlight as this may damage the filter.
6. Replace the filter back into the unit, with mesh side facing fan, by aligning tabs with the slots and turning clockwise to secure the filter in place.
7. Plug the adaptor back into the unit and then plug into wall outlet.
8. Turn on machine.

* For normal household use, clean the filter every 30 days.



MODEL: JMS17372

Adaptor	In-put 100-240VAC	Out-put DC24V1A
Max. Power	20W	
Water Tank Capacity	26oz	
Humidity on Low Speed	15 hours approximate run time	Water used 1.85oz/per hour approximately
Humidity on Med Speed	7 hours approximate run time	Water used 4oz/per hour approximately
Humidity on High Speed	5 hours approximate run time	Water used 5.40oz/per hour approximately

WARNING: THIS IS A HUMIDIFIER NOT A TOY TO REDUCE THE RISK OF PERSONAL INJURY AND ELECTRIC SHOCK, IT SHOULD NOT BE PLAYED WITH OR PLACED WHERE SMALL CHILDREN CAN REACH IT.
ATTENTION: Cet humidificateur n'est pas un jouet. Pour prévenir les risques de blessure corporelle ou de choc électrique il ne doit pas être utilisé comme jouet ni laissé porté des enfants.

WARNING:


Be sure to read all instructions, warnings and precautions carefully before using this product. Failure to do so could result in injury to you or damage to the unit.

Features:

- Humidifies and purifies the air to give your room a pleasant climate all year round with the bonus of Forever Fragrant®.
- Mist Humidifier delivers just the right level of humidity to turn dry air into a comfortable environment.
- Easy clean reusable filter that removes dust, pollen and allergens from the air.
- 2 different timer functions to fit your lifestyle.
- Adjustable Fan Speeds to increase/decrease scent & humidity disbursement
- 2 Forever Fragrant® discs in Clean Air-scent that neutralize, eliminate odor, and provide subtle scent for up to 2 years. Simply insert discs.
- Fully Assembled.


Parts/Product Components:

- Forever Fragrant® Discs (2)
- Water Tank
- Water Tank Plug
- Cover Plate
- Water Reservoir
- Filter
- Adaptor socket
- Adaptor



Button Features Diagram:

- Humidity light for Humidifier only
- ON/OFF switch for Air Purifier
- Air Purifier Speed - Low
- Air Purifier Speed - Hi
- Timer Buttons - 2 Hours & 5 Hours
- Air Purifier ON/OFF Indicator Light (Blue is on)



SAVE THESE INSTRUCTIONS
INTENDED FOR HOUSEHOLD USE ONLY

Button Features Guide:

1. Humidifier Switch

- Press one time - Light mist - Light white light
 - Press two times - Medium mist - Medium white light
 - Press three times - Heavy mist - Bright white light
 - Press four times to shut the humidifier off
- B. Water low/Purple light



2. Air Purifier Buttons

- Press ON/OFF to activate.
- Press "Low" for Low Speed, or "Hi" for High Speed.

If using both the Humidifier and Air Purification, enable the desired Humidifier strength before activating Air Purifier.


If you enable the Humidifier after your desired Air Purification speed, purification speed to a very low setting. Then - simply press either Low or Hi to desired purification speed.

3. Timer Buttons

- 2 Hours - 2 hours on, 2 hours off - repeat cycle until unit is turned off. Blue light will flash every second when set.
- 5 Hours - 5 hours on, 5 hours off - repeat cycle until unit is turned off. Blue light will flash every 2 seconds when set.

HOW TO FILL

Plug adaptor into unit before plugging into wall socket.
Remove Forever Fragrant® Discs before filling unit.



- Remove Water Tank from base
- Remove Water Tank plug
- Fill with 26oz water or until you hit the "Max" fill line
- Replace Tank Cap and place water tank back on Humidifier base

IMPORTANT SAFEGUARDS

IN ORDER TO AVOID ELECTRICAL SHOCK, FIRE AND/OR SERIOUS PERSONAL INJURY, WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS

2. Check that the voltage power corresponds to that stated on the appliance.
3. To protect against electrical shock do not immerse cord, plugs, power base or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used near children. This product is not a toy and should be used out of reach of children. This product shall not be used by children, without close supervision.
5. Unplug from outlet when not in use and before cleaning.
5. Do NOT operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do NOT use outdoors.
9. Do NOT let cord hang over edge of table or counter, or touch hot surfaces.
10. Do NOT place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, put the switch in off position, then remove plug from wall outlet.
12. Do NOT use appliance for other than intended use.
13. When removing mineral deposit, only use products specially formulated for the removal of mineral deposit. Never use ammonia or any other substance that might be dangerous to your health.
14. Do NOT refill with water while the appliance is switched on.
15. Use on a water resistant, hard, flat level surface only.
16. NEVER use the appliance if it has been dropped on the floor or damaged in any way.
17. Always have water in the water tank when operating the unit.
18. Use only clean, cool tap water to fill the tank (softened or distilled water is recommended, if tap water is hard).
19. To avoid white dust, you may use distilled water.
20. Be sure that the filling cap of the tank is firmly tightened.
21. Always have the mist direction nozzle and the mist chamber in place while the unit is operating. Rotate the appliance so that the mist nozzle aims away from children, walls and furniture.
22. Do not add medication of any type into the nozzle, base or water tank. Do not cover any openings on the unit or insert objects into any openings.
23. The unit should not be left unattended in closed rooms as the air could become saturated and leave condensation on walls or furniture. Always leave the room door partly open.
24. When cleaning the inside of the unit, keep water away from the air outlet. The exterior may be wiped with a damp cloth, except the electrical controls, when the unit is off. (Any part may be wiped with a damp cloth when the unit is unplugged.)
25. Do not tilt or tip the unit or attempt to empty or fill it while it is in operation.
26. If using detergent to clean any parts of the unit that contains water use detergent sparsely and rinse abundantly. Detergent deposit dissolved in the water supply might interfere with the output of the unit.
27. HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS!

Two Year Limited Warranty

Congratulations on your purchase of Joy Mangano Forever Fragrant AirFLO™ Humidifier/Air Purifier. This product is warranted to be free from defects in material and workmanship under normal use and service for a period of two years from the date of purchase with original receipt. The manufacturer's obligation shall be limited to replacing with same or like product, FOB NY, the product that is defective. Such warranty shall not apply to damages from accidents, abuse, misuse, normal wear and tear or damage due to abusive handling. This warranty is valid only for first quality goods purchased from an authorized selling agent of IDL 10/16

Ingenious Designs LLC • 2060 9th Avenue • Ronkonkoma, NY 11779 • (800) 248-3002
Made in China
www.joymangano.com



FOREVER FRAGRANT
AirFLO™
HUMIDIFIER/AIR PURIFIER

USER
GUIDE