

volkano™

Leo Series



TRUE WIRELESS **EARPHONES** WITH CHARGING CASE



INSTRUCTION MANUAL

Please read and retain these instructions for future reference.



VK-1130-BK

HIGHLIGHTS

- True Wireless Bluetooth® Technology
- Hands-Free Calling
- Portable Charging Case gives up to 12 Hours Playtime
- True Stereo Sound


PACKAGE CONTENTS

- Volcano Leo Series True Wireless Stereo Earphones
- USB Charging Cable
- 300 mAh Charging Case
- Instruction Manual
- 3 x Earbud Cap Sizes

SPECIFICATIONS

- Bluetooth®:
 - o Version: 5.0
 - o Chipset: JL
 - o Profiles: HFP, HSP, A2DP, AVRCP
 - o Range: 10 m / 33 ft
- Charging Case:
 - o Battery: 300 mAh
 - o Number of Recharges: 4 x
 - o Charging Time: 1 Hour
 - o Charge Input: 5 V DC
- Earphones:
 - o Battery: 2 x 30 mAh
 - o Charging Time: 1 ~ 2 Hours
 - o Playback Time: 2.5 ~ 3 Hours
 - o Sensitivity: 101 dB
 - o Driver Size: 6 mm
 - o Impedance: 32 Ω
 - o Frequency Response: 20 Hz ~ 20 kHz

IDENTIFYING PARTS



1. Charging Case
2. Multi-function Button
3. LED Indicator Light
4. Earbud Cap

INSTRUCTIONS FOR USE

CHARGING THE CASE

- Please ensure that the battery is fully charged before using the device for the first time.
- Connect the provided USB Charge Cable to the Micro USB charging slot on the charging case, connect the other end of the USB to a wall charger or an available USB port on a compatible device.
- The LED Indicator Light on the Charging Case will flash red while charging.
- When charging is complete, the LED Indicator Light will stop flashing and stay on.

CHARGING THE EARPHONES

- Please ensure that the battery is fully charged before using the device for the first time.
- Place the earphones into the charging case, charging begins automatically.

Note:

- Charge time is approximately one to two hours. Earphones cannot be used while charging.
- The earphones will turn off when inserted into the charging case, even if they are powered ON before charging.

SWITCHING THE EARPHONES ON & OFF

- **Switching the Earphones On:** The earphones automatically switch on when removed from the charging case.
- **Switching the Earphones Off:** The earphones automatically switch off when placed back into the charging case and can also be switched off manually by pressing and holding the Multi-function Button for about 4 seconds or until the LED light turns off.

PAIRING THE EARPHONES WITH EACH OTHER

Remove both earphones from the Charging Case at the same time, the earphones will automatically switch on, the LED Indicator Lights on both earphones will flash blue-red while pairing with each other.

When the earphones are paired, they will enter Bluetooth® Pairing Mode and only one of the earphones LED Indicator will flash blue-red.

PAIRING WITH BLUETOOTH® DEVICES

Your earphones must be paired to a Bluetooth® device before it can be used. It is only necessary to pair your earphones once with each device.

1. Ensure that your device's Bluetooth® is on. Search for the device "Leo".
Confirm pairing by selecting the device from the list.
2. When successfully paired, the earphone will emit the voice prompt "connected".
3. The device is now ready to make / receive calls and play audio.

LOCATING THE BLUETOOTH® MENU

iPhone, iPad, and iPod Touch

- a) On your device, go to Settings.
- b) Select Bluetooth®. If Bluetooth® is not on, turn it on.
- c) The iPhone / iPad / iPod will automatically search for new devices.

Android™ Phones and Tablets

- a) On your device, go to the Settings Menu.
- b) Select Bluetooth® (on older Android devices Bluetooth® is found in the Wireless & Networks Menu). If Bluetooth® is not on, turn it on.
- c) Select "Search for Devices" if your phone or tablet does not automatically search for new devices.

Note: If you are unsure of how to access your Bluetooth® Menu on your device, please refer to your device's instruction manual.

CONTROLS

AUDIO CONTROLS

Function	Operation
Play or Pause Track	Short press the Multi-function Button.
Navigate to Next Track	Short press the Multi-function Button three times.

PHONE CALLS

Function		Operation
Incoming Call	Answer Call	Short press the Multi-function Button.
	Reject Call	Press and hold the Multi-function Button.
Call in Progress	End Call	Short press Multi-function Button.
Call your last dialled number		Double press the Multi-function Button

TROUBLESHOOTING

1. My smartphone cannot find any new Bluetooth® devices?

- a. Ensure the device has entered the pairing mode.
- b. Ensure the device is within an effective working range.

2. Bluetooth® device cannot pair up?

Ensure your mobile phone allows new connections and has not reached the maximum number of allowed devices.

3. The device does not play music when it is connected to a Bluetooth® mobile phone.

- a. Ensure your mobile phone supports A2DP profiles.
- b. Ensure your mobile phone is within an effective working range.

4. When paired with my computer, Windows® asks for a new driver.

Can you supply this?

We recommend you find compatible drivers for your computer online.

5. Why can I not remotely control the Pause / Play / Previous / Next functions when music is playing?

This feature needs the Bluetooth® device paired with the speaker to support AVRCP (Audio / Video Remote Control Profile). Please ensure your device supports this.

SAFETY PRECAUTIONS

- This product is not intended for commercial use and has been tested for household use only.
- This product is not intended for use by small children, or persons with diminished mental capabilities. Ensure that the use of this product is monitored by a guardian or parent.
- Never use your earphones near water or in areas where it can come into contact with water. Never handle the earphones if they have been dropped into water or any other liquid. If the product comes into contact with water while charging, this is a safety hazard.
- Do not operate the product after it malfunctions, it has been dropped or damaged in any way.
- **WARNING:** Always keep optional accessories, small parts and packaging out of the reach of babies and small children, as these items may be a choking hazard.
- **DO NOT** overcharge your Volcano Leo Series True Wireless Stereo Earphones and Charging Case, doing so will shorten the lifespan of the built-in batteries and could cause your device to overheat.
- **CAUTION:** Do not disassemble the battery or dispose of it in a fire.
- **CAUTION:** Should your battery show signs of overheating, smoke or fumes being emitted during charging, remove the charging cable immediately.

CLEANING AND CARE INSTRUCTIONS - GENERAL

- **Before Cleaning:** Ensure that your Volcano Leo Series True Wireless Stereo Earphones and Charging Case are turned off before cleaning or maintaining your device.
- **Cleaning:** Wipe down the surface of your Volcano Leo Series True Wireless Stereo Earphones and Charging Case using a soft, slightly damp cloth.
- Do not use any harsh or abrasive cleaning chemicals or materials on your Volcano Leo Series True Wireless Stereo Earphones and Charging Case as doing so may damage or scratch the surface finish.
- Do not expose your Volcano Leo Series True Wireless Stereo Earphones and Charging Case to direct sunlight or high temperatures for extended periods of time.
- Do not store in temperatures over 60°C.
- Do not expose the battery to excessive heat such as sunshine, fire or the like. Store in a cool, dry place.


ENVIRONMENTALLY FRIENDLY DISPOSAL

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE ON WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT.



At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin. Do not dispose of in fire.

Please be responsible and recycle this product and its packaging.

 WARNING	This product can expose you to chemicals including styrene, ethylbenzene, and cumene, which are known to the State of California to cause cancer. For more information go to www.P65Warning.ca.gov .
---	---

DISCLAIMER

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Volkano™ is under license. Other trademarks and trade names are those of their respective owners.

All product and company names are trademarks™ or registered® trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by them.

WARRANTY

This Volcano Leo Series True Wireless Stereo Earphones with Charging Case comes with a standard 12-month limited warranty against manufacturing defects and faults. Should your product be unboxed with any faulty parts, poor finishing or visible damage, or fail to perform due to a manufacturing defect or poor workmanship, please return it with your proof of purchase (till slip or invoice) to the store of purchase for an exchange, or repair, depending on the store's returns policy.

This warranty commences from the date of purchase.

Kindly retain your proof of purchase as well as the packaging for your warranty period.

NOTE:

The Warranty does not apply to a product that:

- a. Has failed due to excessive wear and tear beyond what is considered to be reasonable.
- b. Has been misused or neglected.
- c. Has been damaged accidentally or by acts of God including fire and flooding.
- d. Has been used or operated contrary to operating or maintenance instructions outlined in this manual.

The Store of Purchase / Seller cannot accept any returned products that have not been returned in accordance with this warranty or which do not follow their own Returns Policy. Please refer to the Store of Purchase / Sellers Returns Policy for details.

Should you require any further assistance or have any questions on your warranty, please contact the store of purchase.