

REHEATZA[®]

MICROWAVE
CRISPER

For Tips and Tricks visit: www.ReheatzaTips.com

©2017 Allstar Products Group Hawthorne, NY 10532.
Reheatza is a registered trademark of Joseph Kanefsky.
Product distributed by APG.
Patent Pending. Made in China.

REHEATZA[®]

MICROWAVE
CRISPER

INSTRUCTION MANUAL



For Tips and Tricks visit: www.ReheatzaTips.com

How It Works

Microwave-safe lid shields food from microwave energy, preventing food from being directly microwaved.

Pan gets heated by the heating element in the base. Converts microwave energy to conductive heat like your oven/stove top.

Heating element located beneath the pan in the base. Heats quickly up to 400° F.

1

Cleaning

The Reheatza® pan is **NOT** dishwasher safe. Only clean it by hand, and make sure to **NEVER** submerge the Reheatza® pan underwater. Submerging the pan can cause the unit to malfunction.

Avoid water from getting into the base.



The Reheatza® pan should only be cleaned using a slightly damp, soft cloth or sponge. To clean, use a slightly damp cloth or sponge to remove food splatters or food particles. Wipe clean with a dry towel. Always allow Reheatza® pan to fully cool before cleaning.

18

S'MORES

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 3:00 instead of 2:00 during step 2.

Step 1 – Assemble your S'mores by placing 1 piece of chocolate and 1 marshmallow between 2 graham crackers. Do this twice.

Step 2 – Preheat the Reheatza[®] pan without the lid in the microwave for 2:00.

Step 3 – Remove the Reheatza[®] pan from the microwave and place the 2 assembled S'mores onto the pan.

Step 4 – Cover with the lid, insert the Reheatza[®] pan back into the microwave, and cook for 1:00.

Step 5 – Remove from microwave and enjoy your snack!


TIP: If your S'mores are not melted enough, let them rest on the Reheatza[®] pan for an additional 30 seconds.



Safety Instructions and Warnings

- Read all instructions before using the Reheatza[®] pan. Use only for its intended purpose as described in this manual.
 - **Never use the Reheatza[®] pan with the convection setting on your microwave. Do not attempt to use the Reheatza[®] pan in a microwave where the original turntable has been damaged or removed, and ensure the Reheatza[®] pan can freely rotate in the microwave before use.**
 - Keep out of reach of children and pets.
 - Do not operate the Reheatza[®] pan if it is not functioning properly or if it has been chipped, cracked, damaged, or dropped.
 - Do not leave Reheatza[®] pan unattended while in use.
 - Should sparking, arcing, or any other unusual malfunction occur during cooking operation, cut power to the microwave immediately and discontinue all further use of the Reheatza[®] pan.
 - Always use oven mitts or pot holders to insert or remove the Reheatza[®] pan from your microwave. Make sure to keep the pan level while removing to prevent possible injury.
 - After preheating or cooking, open the Reheatza[®] pan carefully away from your face to avoid hot steam or grease splatter.
 - Children should not be permitted to use the Reheatza[®] pan.
 - Never submerge the Reheatza[®] pan. It may not function properly if water enters the base of the pan.
 - Not dishwasher safe.
 - **HAND WASH ONLY.** Follow the cleaning instructions in this manual only.
- Reheatza[®] pan will work in most microwaves with interior dimensions only greater than or equal to: 12.5" L x 12.5" W x 5" H. DO NOT USE IN MICROWAVES THAT ARE SMALLER.**

What's Included



3

BACON

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 3:00 instead of 2:00 during step 1.

- Step 1 – Preheat the Reheatza[®] pan without the lid in the microwave for 2:00.
Step 2 – Remove the Reheatza[®] pan from the microwave and place 4 pieces of bacon onto the pan.
Step 3 – Cover with the lid, insert the Reheatza[®] pan back into the microwave, and cook for 2:00.

CAUTION: Make sure to keep the Reheatza[®] pan level when removing to prevent any hot liquids or grease from spilling.

- Step 4 – Remove the Reheatza[®] pan from microwave and flip the bacon. Cover and place back in the microwave and cook for 4:00.
Step 5 – Remove from microwave and enjoy your meal!

TIP: If your bacon is not cooked fully, microwave with the lid on for 30 second intervals until fully cooked.



16

SCRAMBLED EGGS

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 3:00 instead of 2:00 during step 2.

- Step 1 – Crack 2 eggs into a cup or bowl and stir until mixture is consistent.
- Step 2 – Preheat the Reheatza® pan without the lid in the microwave for 2:00.
- Step 3 – Remove the Reheatza® pan from the microwave and pour the egg mixture onto the pan.
- Step 4 – Cover with the lid, insert the Reheatza® pan back into the microwave, and cook for 1:00.
- Step 5 – Remove the Reheatza® pan from microwave and stir the eggs with a spatula. Cover and place back in the microwave and cook for 0:30.
- Step 6 – Remove from microwave and enjoy your meal!

TIP: If your scrambled eggs are not cooked fully, microwave with the lid on for 30 second intervals until fully cooked.



Handle Assembly

Assemble by placing the two Silicone Washers around the center hole of the Lid on both sides of the Lid. Place the Lid Handle on top and handtighten the Bolt until the Handle is secured tightly. If you are having trouble hand tightening, use a wrench to hold the bolt in place while tightening down the Handle.

The Reheatza® pan may not function if handle is improperly installed.



General Cooking Instructions

- Cook times are based on a 1200 W microwave.
- Always use oven mitts or pot holders while handling the Reheatza® pan.



NOTE: When removing the Reheatza® pan from the microwave oven, always remember to use oven mitts or pot holders.

Only place the base of the Reheatza® pan into the microwave. Refer to Figure 1 above.
If you have a 1200W microwave, preheat by cooking on high for 2 minutes (do not exceed 2 minutes).
If your microwave is less than or equal to 1100W, preheat by cooking on high for 3 minutes (do not exceed 3 minutes).

When done, remove using oven mitts or pot holders.

NOTE: Your Reheatza® pan must be preheated before cooking food.

5

FROZEN MOZZARELLA STICKS

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 2:30 instead of 1:30 during step 1.



- Step 1 – Preheat the Reheatza® pan without the lid in the microwave for 1:30.
Step 2 – Remove the Reheatza® pan from the microwave and place 4-6 pieces of frozen mozzarella sticks onto the pan.
Step 3 – Insert the Reheatza® pan back into the microwave, and cook for 0:30 without the lid.
Step 4 – Place the lid onto the Reheatza® pan and cook for an additional 0:45.
Step 5 – Remove the Reheatza® pan from microwave and flip the mozzarella sticks. Cover and place back in the microwave and cook for 0:45.
Step 6 – Remove from microwave and enjoy your meal!

TIP: If your mozzarella sticks are not cooked fully, microwave with the lid on for 30 second intervals until fully cooked.

14

FRESH STEAK

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 3:00 instead of 2:00 during step 1.

NOTE: Depending on the thickness of the steak, you may need to cook for longer than instructed below. The instructions below are for a 0.5" thick steak.

- Step 1 – Preheat the Reheatza[®] pan without the lid in the microwave for 2:00.
- Step 2 – Remove the Reheatza[®] pan from the microwave and place the steak onto the pan.
- Step 3 – Cover with the lid, insert the Reheatza[®] pan back into the microwave, and cook for 4:00.
- Step 4 – Remove the Reheatza[®] pan from microwave and flip the steak. Cover and place back in the microwave and cook for 2:00.
- Step 5 – Remove from microwave and enjoy your meal!

TIP: If your steak is not cooked fully, microwave with the lid on for 30 second intervals until fully cooked.



Place the food to be cooked on top of the Reheatza[®] pan. Center and place the lid on top of the base.



Place the Reheatza[®] pan in the microwave oven. Make sure it is on a level surface and centered so that it cannot hit the walls when rotating.

Ensure Reheatza[®] pan can rotate freely on the turntable. Do not use if the pan cannot rotate freely or if the turntable of the microwave has been removed or damaged.

Cooking Guide

4

Cook the food based on the guidelines in this manual. For other foods not listed in this manual (pages 9-13), follow these general instructions:

General Instructions

Frozen Snacks

1. Preheat the Reheatza[®] pan without the lid for 2 minutes (1200W microwave) or 3 minutes (1100W or below microwave)
2. Place frozen food onto the pan and cover with lid. Cook for 2 minutes.
3. If food needs to be flipped, flip it using a spatula or fork and cook for an additional 2 minutes with the lid on.
4. If additional time is needed, cook for intervals of 30 seconds without the lid until fully cooked.

Refrigerated Leftovers

1. Preheat the Reheatza[®] pan without the lid for 2 minutes (1200W microwave) or 3 minutes (1100W or below microwave)
2. Place food onto the pan and cover with lid. Cook for 2 minutes.
3. If food needs to be flipped, flip it using a spatula or fork and cook for an additional 2 minutes with the lid on.
4. If additional time is needed, cook for intervals of 30 seconds without the lid until fully cooked.

Fresh Meats

1. Preheat the Reheatza[®] pan without the lid for 2 minutes (1200W microwave) or 3 minutes (1100W or below microwave)
2. Place food onto the pan and cover with lid. Cook for 3 minutes.
3. Flip the food using a spatula or fork and cook for an additional 2 minutes with the lid on.
4. If additional time is needed, cook for intervals of 30 seconds without the lid until fully cooked.

7

FRESH SHRIMP

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 3:00 instead of 2:00 during step 1.

- Step 1 – Preheat the Reheatza[®] pan without the lid in the microwave for 2:00.
- Step 2 – Remove the Reheatza[®] pan from the microwave and place 4-8 pieces of fresh deshelled shrimp onto the pan.
- Step 3 – Cover with the lid, insert the Reheatza[®] pan back into the microwave, and cook for 2:00.
- Step 4 – Remove the Reheatza[®] pan from microwave and flip the shrimp. Cover and place back in the microwave and cook for 2:00.
- Step 5 – Remove from microwave and enjoy your meal!

TIP: If your shrimp are not cooked fully, microwave with the lid on for 30 second intervals until fully cooked.



12

GRILLED CHEESE SANDWICH

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 3:00 instead of 2:00 during step 2.

Ingredients: 2 pieces of sliced bread, 2 oz cheese, 2 tbsp butter

Step 1 – Assemble your grilled cheese sandwich on a separate plate. Butter the two outside pieces of bread with 1 tbsp of butter on each side and place the cheese in between.

Step 2 – Preheat the Reheatza® pan without the lid in the microwave for 2:00.

Step 3 – Remove the Reheatza® pan from the microwave, place the assembled grilled cheese sandwich onto the pan, and cover with the lid. Insert the Reheatza® pan back into the microwave and cook for 1:30.

Step 4 – Remove the Reheatza® pan from microwave and flip the grilled cheese sandwich. Cover and place back in the microwave and cook for 0:30.

Step 5 – Remove from microwave and enjoy your meal!

TIP: You can grill further by letting the Grilled Cheese rest while on the heated Reheatza® pan. If it is not cooked enough, cook with lid on for 30 second intervals.



Carefully remove the Reheatza® pan from the microwave oven using oven mitts or potholders. The Reheatza® pan will be hot. Keep the Reheatza® pan level when removing from the microwave oven or when removing food from it to prevent any hot liquids from spilling.

Remove the lid of the Reheatza® pan and enjoy your hot meal!

REHEATING LEFTOVER PIZZA

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 2:30 instead of 1:30 during step 1.

Step 1 – Preheat the Reheatza® pan without the lid in the microwave for 1:30.

Step 2 – Remove the Reheatza® pan from the microwave and place a cold slice of pizza onto the pan.

Step 3 – Cover with the lid, insert the Reheatza® pan back into the microwave, and cook for 2:00.

Step 4 – Remove from microwave and enjoy your meal!

TIP: If you need to cook pizza further, cook for 30 second intervals. If you only need the cheese to melt further, remove the lid and cook for 15 seconds.



FROZEN PIZZA

IMPORTANT: Cooking instructions are based on a 1200W microwave. If you are using a microwave that has power less than or equal to 1100W, preheat for 3:00 instead of 2:00 during step 1.

Step 1 – Preheat the Reheatza® pan without the lid in the microwave for 2:00.

Step 2 – Remove the Reheatza® pan from the microwave and place a small frozen pizza onto the pan.

Step 3 – Cover with the lid, insert the Reheatza® pan back into the microwave, and cook for 2:00.

Step 4 – Remove the lid of the Reheatza® pan and microwave for another 0:30 seconds. If the pizza is not cooked completely, cook for an additional 0:30 seconds.

Step 5 – Remove from microwave and enjoy your meal!

TIP: If you need to cook pizza further, cook for 30 second intervals. If you only need the cheese to melt further, remove the lid and cook for 15 seconds.





Cooking Guide

700W-1100W Cooking Guide

Food	Preheat (No Lid)	Cooking Instructions* (After Preheating the Pan)
Reheating Pizza	2:30	Cook for 2:00-3:00 depending on the size and quantity of slices. For extra cheese melting, cook for an additional 0:30 without the lid.
Frozen Pizza	3:00	Cook for 2:00. For extra cheese melting, cook for an additional 0:30 without the lid.
Grilled Cheese Sandwich	3:00	Cook for 1:30, flip the sandwich, and cook for an additional 0:45.
Fresh Shrimp	3:00	Cook for 2:00, flip the shrimp, and cook for an additional 2:00.
Fresh Steak**	3:00	Depending on the thickness of your steak, cook for 4:00-5:00, flip the steak, and cook for an additional 2:00-4:00.
Frozen Mozzarella Sticks	2:30	Cook for 0:30 without the lid. Cover with lid and cook for additional 0:45. Flip the mozzarella sticks and cook for an additional 0:45.
Scrambled Eggs	3:00	Cook for 1:00, stir and flip the eggs, and cook for an additional 0:30.
Bacon	3:00	Cook for 2:00, flip the bacon, and cook for an additional 4:00.
S'mores	3:00	Cook for 1:00.
*Cook using the lid unless specified. Always preheat the pan without the lid. If your food needs additional time, cook in 0:30 second intervals with the lid.		
**Steak cooking time depends on the thickness of the steak. Thicker steaks (greater than 0.5" thick) will need to be cooked longer.		

For Tips and Tricks visit: www.ReheatzaTips.com

1200W+ Cooking Guide

Food	Preheat (No Lid)	Cooking Instructions* (After Preheating the Pan)
Reheating Pizza	1:30	Cook for 2:00-3:00 depending on the size and quantity of slices. For extra cheese melting, cook for an additional 0:30 without the lid.
Frozen Pizza	2:00	Cook for 2:00. For extra cheese melting, cook for an additional 0:30 without the lid.
Grilled Cheese Sandwich	2:00	Cook for 1:30, flip the sandwich, and cook for an additional 0:45.
Fresh Shrimp	2:00	Cook for 2:00, flip the shrimp, and cook for an additional 2:00.
Fresh Steak**	2:00	Depending on the thickness of your steak, cook for 4:00-5:00, flip the steak, and cook for an additional 2:00-4:00.
Frozen Mozzarella Sticks	1:30	Cook for 0:30 without the lid. Cover with lid and cook for additional 0:45. Flip the mozzarella sticks and cook for an additional 0:45.
Scrambled Eggs	2:00	Cook for 1:00, stir and flip the eggs, and cook for an additional 0:30.
Bacon	2:00	Cook for 2:00, flip the bacon, and cook for an additional 4:00.
S'mores	2:00	Cook for 1:00.
*Cook using the lid unless specified. Always preheat the pan without the lid. If your food needs additional time, cook in 0:30 second intervals with the lid.		
**Steak cooking time depends on the thickness of the steak. Thicker steaks (greater than 0.5" thick) will need to be cooked longer.		

©2017 Allstar Products Group Hawthorne, NY 10532.
 Reheatza is a registered trademark of Joseph Kanefsky.
 Product distributed by APG.
 Patent Pending. Made in China.

For Tips and Tricks visit: www.ReheatzaTips.com